

Operating Voltage Setup

IMPORTANT

This setup applies to 208–240V units only!

All 208–240 Volt units are factory preset for 240V. If the operating voltage is not 240 Volts, the DIP switches must be set for the actual voltage, so that the low-speed setting of the fans will be correct. The switch is accessible through a hole in the back cover of the Frigitek. **Do not remove the back cover.**

